

Manual to HiRA HV control interface

Release 0.1

February 2004 by Michal Mocko

Before starting:

Make sure the SY2527 (caenhv05) is up and running with ethernet cable connected. Find out the IP number corresponding to caenhv05 (they change it quite often). You can enable the remote control by flipping the switch on SY2527 to "remote" and plugging a TTL signal into the LEMO connector. Then we are ready to run telnet or HiRA_HV_control GUI.

The default directory is HiRA_HV_control where the following file structure is stored:

<spdaq10:HiRA_HV_control >ls

README_caenctl ← readme file explaining caenctl tcl/tk expansion

HiRAChannelAssignment.tcl ← contains channel mapping (must be modified if one changes card position or cables)

HVControl.tcl ← main tcl script containing the interface

HiRAControl.tcl ← tcl/tk procedures defining HiRA specifics


caenctl* ← executable of tcl/tk expanded for SY2527 control

SaveStatus/ ← directory which can contain log files

Config/ ← directory containing *.hira and *.config files

goHVhira* ← script starting the interface

check files before starting and then type ./goHVhira to start the interface:




Viewing and setting channel parameter values:

First of all we have to log in to the HV power supply. Go to HV Power Supply → Login to PS:

The default values are shown in the left figure. HV name is just internal name which is used to address the power supply. IP number is the IP number of the SY2527 power supply. User name and password does not have to be changed. After hitting Login button one should see the following:



If there is an error message there is something wrong with connection to Power supply (PS). Check if PS is on and if the network path exists (e.g. running ping).



Crate map (map which slots are occupied and which not) is displayed by selecting View → Crate Map menu.

Example of Crate map is shown below:

Slot	No of Channels	HV Card Description	Serial
Slot 0	12	12 Ch Float 250V 1/0.1mA	84
Slot 1	12	12 Ch Float 250V 1/0.1mA	83
Slot 2	0	No Card Present	0
Slot 3	0	No Card Present	0
Slot 4	28	28 Ch Neg. 3KV 3mA	17
Slot 5	0	No Card Present	0

Cards IN

Cards not present

Checking channel parameter values for a chosen slot:

By selecting View→Card Number→Slot 0 one can see status of card located in slot number 0. In my case one sees:

Number	Channel Name	Volt Set	Volt Mon	Current Mon	Current Set	Soft VMax	Power	Ramp Up	Ramp Down	Status
0	LVB13	10.0	10.1	0.0	2.0	20.0	On	1.0	1.0	ON
1	LVB16	10.0	0.0	0.0	2.0	20.0	Off	1.0	1.0	OK
2	LVB14	10.0	9.6	0.0	2.0	20.0	On	1.0	1.0	ON
3	LVB17	10.0	0.0	0.0	2.0	20.0	Off	1.0	1.0	OK
4	LVB15	10.0	9.9	0.2	2.0	20.0	On	1.0	1.0	ON
5	LVB18	10.0	9.6	0.0	2.0	20.0	On	1.0	1.0	ON
6	LVB19	10.0	0.0	0.0	2.0	20.0	Off	1.0	1.0	OK
7	LVB20	10.0	0.2	0.0	3.0	80.0	Off	1.0	1.0	OK
8	LVB20	10.0	0.2	0.0	2.0	20.0	Off	1.0	1.0	OK
9	LVB23	10.0	0.0	0.0	3.0	80.0	Off	1.0	1.0	OverCurrent (Int. trip)
10	LVB21	10.0	2.7	0.0	3.0	80.0	On	1.0	1.0	ON Up
11	LVB24	10.0	0.3	0.2	3.0	80.0	Off	1.0	1.0	OK

Colors meaning:

Black on Green background – channel is ON

Yellow on Blue background – channel is OFF

Black on Red background – problem!!!

Setting channel parameter values:

By selecting Set→Set Parameters one gets dialog as follows:

And one can set any channel parameter through this dialog by selecting appropriate Set/Do not check button underneath a parameter. In the above example after hitting Set button I am setting channel number 10 on slot number 1 ON. By checking All channels/Only specified one sets the same parameter value for all channels in a gives slot number. One can see the results of set actions immediately in View→Card Number→Slot 1.

HiRA telescope voltage/current monitoring:

Loading configuration for a given experiment:

There are two different configuration files. First containing information about Towers and Telescopes used and other about voltage and current limits to be set for all the detectors connected to the tower numbers.

Files with extension *.hira contain tower number used and telescope number connected to it in the following format:

```
!  
tower0  
telescope0 E HVB2  
telescope0 dE LVB6  
telescope1 E HVB1  
telescope1 dE LVB3  
telescope2 E HVB26  
telescope2 dE LVB2  
telescope3 E HVB5  
telescope3 dE LVB1  
telescope4 E HVB4  
telescope4 dE LVB5  
common Csl LVB22  
tower1  
telescope5 E HVB7  
telescope5 dE LVB9  
telescope6 E HVB6  
telescope6 dE LVB8  
telescope7 E HVB27  
telescope7 dE LVB7  
telescope8 E HVB10  
telescope8 dE LVB4  
telescope9 E HVB9  
telescope9 dE LVB12  
common Csl LVB23  
!  
END
```

First of all “!” is a comment character for both configuration files. Everything between keywords towerX and towerY or anything between towerX and END is considered to be connected to towerX. Keyword dE or E or Csl defines detector which is connected to appropriate High/Low Voltage Bias (H/LVB). Keyword of common is to be used only for Csl detectors because they are connected through different cable(connector). Mapping of H/LVBs is defined in file: **HiRAChannelAssignment.tcl** that’s why it is **essential to make appropriate changes** in this file if one of the cards is relocated within the power supply or there are changes made in cabling.

Second configuration file (*.config) contains voltage and current limits to be set for **all** detectors defined in the *.hira file. Syntax is straightforward and easy to understand:

```

!
telescope0
dE 10 2
E 300 2.0
telescope1
dE 10 2
E 300 2.0
telescope2
dE 10 2
E 300 2.3
telescope3
dE 10 2
E 300 3
!
CsI
tower0 10 3
!

```

Again “!” is a comment character. And keywords of dE and E mean appropriate detectors for telescopeX (above them) and then voltage and current limits are defined (in that order). Again CsI detector biases are defined out of telescopes because they share bias voltage from one source for the whole tower → CsI keyword has to be used and then towerX and voltage and current are defined (in that order).

Configuration files are loaded in the following order:

1. HiRA configuration (HiRA → Open HiRA configuration)
2. Voltage configuration (HiRA → Open Voltage configuration)
3. Log directory (HiRA → Choose Log Directory) = **[optional]**

If all configuration files are loaded properly one can start with View → HiRA status. If there is an error while loading configuration file. Please check the syntax of the file. Another common problem is if the two files (*.hira and *.config) have different towers/telescopes defined. **There has to be the same tower/telescope numbers in both files!**

Selecting View → HiRA status we get:

The screenshot shows the 'HiRA High Voltage control' window. It features a menu bar with 'HV Power Supply', 'View', 'Set', and 'HiRA'. The main area is divided into five panes, one for each tower (tower0 to tower4). Each pane contains a table with columns: Name, V Set, I Set, V Mon, I Mon, Power, Status, and a numerical ID. The 'Power' column has a blue square icon. The 'Status' column shows 'OK' or 'Channel is problematic'. At the bottom, there are controls for 'On/Off All', 'Reverse selection', and 'Un/Lock' for each tower. A status bar at the bottom indicates 'Channel is ON' and 'Channel is in problematic status'.

Name	V Set	I Set	V Mon	I Mon	Power	Status	ID
telescope0 dE	10.0	2	0.0	0.0	OK	OK	0, 5
telescope0 E	300.0	2.0	0.0	0.0	OK	OK	4, 1
telescope1 dE	10.0	2	0.0	0.0	OK	OK	0, 4
telescope1 E	300.0	2.0	0.0	0.0	OK	OK	4, 0
telescope2 dE	10.0	2	0.1	0.0	OK	OK	0, 2
telescope2 E	300.0	2.3	0.0	0.0	OK	OK	4, 25
telescope3 dE	10.0	2	0.0	0.0	OK	OK	0, 0
telescope3 E	300.0	3	0.0	0.0	OK	OK	4, 4
telescope4 dE	10.0	2	0.0	0.1	OK	OK	0, 3
telescope4 E	300.0	2.5	0.0	0.0	OK	OK	4, 3
tower0 Csl	10.0	3	0.2	0.0	OK	OK	1, 7

Again the same coloring scheme is used (explained in the bottom of the window). In the

Name	V Set	I Set	V Mon	I Mon	Power	Status	ID
telescope0 dE	10.0	2	0.0	0.0	OK	OK	0, 5
telescope0 E	300.0	2.0	0.0	0.0	OK	OK	4, 1
telescope1 dE	10.0	2	0.0	0.0	OK	OK	0, 4
telescope1 E	300.0	2.0	0.0	0.0	OK	OK	4, 0
telescope2 dE	10.0	2	0.1	0.0	OK	OK	0, 2
telescope2 E	300.0	2.3	0.0	0.0	OK	OK	4, 25
telescope3 dE	10.0	2	0.0	0.0	OK	OK	0, 0
telescope3 E	300.0	3	0.0	0.0	OK	OK	4, 4
telescope4 dE	10.0	2	0.0	0.2	OK	OK	0, 3
telescope4 E	300.0	2.5	0.0	0.0	OK	OK	4, 3
tower0 Csl	10.0	3	0.2	0.0	OK	OK	1, 7

above figure one can see configuration of all HiRA telescopes loaded. At the first glance one sees all channels are OFF. The window is divided into 5 canvases for 5 towers. Each canvas contains list of all telescopes and appropriate Csl LVB bias as shown

in the above figure.

Turning channel(s) ON/OFF:

Is rather easy. To turn a channel ON one checks the appropriate check button:

Name	V Set	I Set	V Mon	I Mon	Power	Status		
telescope0 dE	10.0	2	0.0	0.0	<input type="checkbox"/>	OK	0,	5
telescope0 E	300.0	2.0	0.0	0.0	<input type="checkbox"/>	OK	4,	1
telescope1 dE	10.0	2	10.1	0.0	<input checked="" type="checkbox"/>	ON	0,	4
telescope1 E	300.0	2.0	0.0	0.0	<input type="checkbox"/>	OK	4,	0
telescope2 dE	10.0	2	0.1	0.0	<input type="checkbox"/>	OK	0,	2
telescope2 E	300.0	2.3	0.0	0.0	<input type="checkbox"/>	OK	4,	25
telescope3 dE	10.0	2	0.0	0.0	<input type="checkbox"/>	OK	0,	0
telescope3 E	300.0	3	0.0	0.0	<input type="checkbox"/>	OK	4,	4
telescope4 dE	10.0	2	0.0	0.1	<input type="checkbox"/>	OK	0,	3
telescope4 E	300.0	2.5	0.0	0.0	<input type="checkbox"/>	OK	4,	3
tower0 Csl	10.0	3	0.2	0.0	<input type="checkbox"/>	OK	1,	7
<input type="checkbox"/> On/Off All	<input type="checkbox"/> Reverse selection		<input type="checkbox"/> Un/Lock		tower0			

Now the status is changed and telescope1 dE detector is fully biased (10V).

By clicking on check button “On/Off All” (lower left corner) all channels for given tower are biased. “Reverse selection” check button turns off all channels which are turned off and vice versa.

V(I) Set columns list values which are set (desired) for each telescope. **V(I) Mon** columns list values which are monitored (response collected from HV power supply).

Status column lists status of the channel (OK or ON means everything is fine with the channel if there is a different status the field is changed to red – indicating the problem). Last two columns describe Slot and Channel number to which the detector is connected.

|| *Attention:* the current limits for detectors are rather low (for semiconductor detectors it is the leakage current). That’s why the program raises the current limit (I Set) by a factor determined by Tcl variable “**FactorCurrent**” defined in file HiRAControl.tcl.

Modifying voltage/current limits:

Is possible after checking **Un/Lock** check button (in the bottom row for each tower):

Name	V Set	I Set	V Mon	I Mon	Power	Status		
telescope0 dE	10.0	2	0.0	0.0	<input type="checkbox"/>	OK	0,	5
telescope0 E	300.0	2.0	0.0	0.0	<input type="checkbox"/>	OK	4,	1
telescope1 dE	10.0	2	10.1	0.0	<input checked="" type="checkbox"/>	ON	0,	4
telescope1 E	300.0	2.0	299.2	0.0	<input checked="" type="checkbox"/>	ON	4,	0
telescope2 dE	10.0	2	10.1	0.1	<input checked="" type="checkbox"/>	ON	0,	2
telescope2 E	300.0	2.3	0.0	0.0	<input type="checkbox"/>	OK	4,	25
telescope3 dE	10.0	2	0.0	0.0	<input type="checkbox"/>	OK	0,	0
telescope3 E	300.0	3	0.0	0.0	<input type="checkbox"/>	OK	4,	4
telescope4 dE	10.0	2	0.0	0.1	<input type="checkbox"/>	OK	0,	3
telescope4 E	300.0	2.5	0.0	0.0	<input type="checkbox"/>	OK	4,	3
tower0 Csl	10.0	3	0.2	0.0	<input type="checkbox"/>	OK	1,	7
<input type="checkbox"/> On/Off All	<input type="checkbox"/> Reverse selection	<input checked="" type="checkbox"/> Un/Lock	tower0					

All fields with yellow background are editable now. One can change Voltage/Current limit for single detector. After the changes are made user can save voltage/current configuration through HiRA→Save Voltage Configuration and selecting a file name. Saved configuration has appropriate format so it can be loaded next time with HiRA→Open Voltage Configuration.

Advice: It is better to keep all editable fields locked whenever not necessary to change voltage/current values to prevent from accidental changes to be made.


Attention: Some detectors share channels (are connected to the same channel of the HV PS). If user modifies parameters for such a detector the same value is modified for the shared channel as well! The same applies for turning ON/OFF channels!

Writing Log file automatically:

In order to write log files (files where status information is saved for each defined detector in the setup) user must select Log File Directory (HiRA→Choose Log Directory). In the lower right corner of the main window (HiRA Status):



User can select frequency of log file writing (default if 10 minutes as shown in the example) and then after checking “**Logging**” check button log file writing starts. Unselecting the check button disables the writing. While writing is active the whole line is illuminated with yellow:



Manual to HiRA HV control interface

Release 1.0

August 2004 by Michal Mocko

HiRA telescope voltage/current monitoring:

Loading configuration for a given experiment:

There are two types of configuration files for HiRA HV control interface. First containing information about Towers and Telescopes used and other about voltage and current limits to be set for all the detectors connected to the tower numbers. Files with extension *.hira contain tower number used and telescope number connected to it in the following format:

```
!  
tower0  
telescope0 E HVB2  
telescope0 dE LVB6  
telescope1 E HVB1  
telescope1 dE LVB3  
telescope2 E HVB26  
telescope2 dE LVB2  
telescope3 E HVB5  
telescope3 dE LVB1  
common Csl LVB22
```

!.....

Which is the same as in the previous version (0.1), but voltage configuration files went through changes. I was asked to include SoftwareMaximum, RampUp and Telescope Name parameters to the voltage configuration file. So the new format is:

```
!  
telescope0  
dE 10 2 20 5 tele0.dE  
E 300 2.0 300 5 tele1.dE  
telescope1  
dE 10 2 20 5 tele1.dE  
E 300 2.0 300 5 tele1.E  
telescope2  
dE 10 2 20 5 tele2.dE  
E 300 2.3 300 5 tele2.E  
telescope3  
dE 10 2 20 5 tele3.dE  
E 300 3 300 5 tele3.E  
Csl  
tower0 10 3 20 5  
!
```

Where the order is as follows: V0Set, I0Set, SVMMax, RampUp after each detector.

I added these two parameters to HiRA Status as well:

HiRA High Voltage control

HV Power Supply View Set HiRA HiRA High Volt

Name	V Set	I Set	SVMax	RU _p	V Mon	I Mon	Power	Status
tel0.dE	2.0	2.0	20.0	3.0	0.0	0.0	<input checked="" type="checkbox"/>	OK 1, 5
tel0.E	3.0	2.0	310.0	3.0	0.2	0.0	<input checked="" type="checkbox"/>	OK 4, 1
tel1.dE	2.0	2.0	20.0	3.0	0.0	0.3	<input checked="" type="checkbox"/>	OK 1, 4
tel1.E	2.0	2.0	320.0	3.0	1.8	0.0	<input checked="" type="checkbox"/>	OK 4, 0
tel2.dE	2.0	2.0	20.0	3.0	0.0	0.0	<input checked="" type="checkbox"/>	OK 1, 2
tel2.E	4.0	2.0	330.0	3.0	0.0	0.0	<input checked="" type="checkbox"/>	OK 4, 25
tel3.dE	2.0	2.0	20.0	3.0	0.2	0.0	<input checked="" type="checkbox"/>	OK 1, 0
tel3.E	6.0	2.0	340.0	3.0	0.2	0.0	<input checked="" type="checkbox"/>	OK 4, 4
tower0 Csl	10.0	3.0	20.0	3.0	0.0	0.0	<input checked="" type="checkbox"/>	OK 2, 7

On/Off All
 Reverse selection
 Un/Lock
 tower0

Detector name Channel is ON
 Detector name Channel is OFF
 Problem ... Channel is in problematic status

So one can edit two more parameters (SVMax and RampUp):

HiRA High Voltage control

HV Power Supply View Set HiRA HiRA High Volt

Name	V Set	I Set	SVMax	RU _p	V Mon	I Mon	Power	Status
tel0.dE	2.0	2.0	20.0	3.0	0.0	0.0	<input checked="" type="checkbox"/>	OK 1, 5
tel0.E	3.0	2.0	310.0	3.0	0.2	0.0	<input checked="" type="checkbox"/>	OK 4, 1
tel1.dE	2.0	2.0	20.0	3.0	0.0	0.3	<input checked="" type="checkbox"/>	OK 1, 4
tel1.E	2.0	2.0	320.0	3.0	1.8	0.0	<input checked="" type="checkbox"/>	OK 4, 0
tel2.dE	2.0	2.0	20.0	3.0	0.0	0.0	<input checked="" type="checkbox"/>	OK 1, 2
tel2.E	4.0	2.0	330.0	3.0	0.0	0.0	<input checked="" type="checkbox"/>	OK 4, 25
tel3.dE	2.0	2.0	20.0	3.0	0.2	0.0	<input checked="" type="checkbox"/>	OK 1, 0
tel3.E	6.0	2.0	340.0	3.0	0.2	0.0	<input checked="" type="checkbox"/>	OK 4, 4
tower0 Csl	10.0	3.0	20.0	3.0	0.0	0.0	<input checked="" type="checkbox"/>	OK 2, 7

On/Off All
 Reverse selection
 Un/Lock
 tower0

Detector name Channel is ON
 Detector name Channel is OFF
 Problem ... Channel is in problematic status

In exactly the same fashion as in the previous version Voltage and Current.

Appendix A:

Compilation and maintenance of the code:

Right now (as of June 9, 2005) the HiRA HV power supply GUI is stored in /user/03014 (test run for HiRA). The directory structure is as follows:

```
<spdaq29:HiRA_HV_control >ls -R
.:
Config/          HiRACHannelAssignment.tcl  README_caenctl  goHVhira*
HVControl.tcl   HiRACHannelAssignment.tcl~ SaveStatus/      src/
HVControl.tcl~  HiRAControl.tcl           caenctl*

./Config:
FourTowers.config Tower0.config  Tower1.config  Tower2.hira
Tower4.config
FourTowers.hira   Tower0.config~ Tower1.hira    Tower3.config
README           Tower0.hira    Tower2.config  Tower3.hira

./SaveStatus:
2004Aug03_14:26:43.log  2004Aug04_10:58:40.log
2004Aug03_16:22:08.log  2005Jun08_17:01:34.log

./src:
HVCaen.cpp        Harness.o          HiRA_HV_howto.pdf  TCLinc/
HVCaen.h          HiRA.config       Lib/
Voltage.config
HVCaen.o          HiRACHannelAssignment.tcl  Log/              caenctl*
HVControl.tcl     HiRAControl.tcl  Makefile          goHVhira*
Harness.cpp       HiRAControl.tcl~ Makefile~         include/
Harness.h         HiRA_HV_howto.doc  README_caenctl   temp.config

./src/Lib:
hscaenetlib.so.1.6  libcaenhvwrapper.so      libhscaenet.so
hvwrapperlibs.tar  libcaenhvwrapper.so.2.11  libhscaenet.so.1.6

./src/Log:
2004Feb02_09

./src/TCLinc:
ErrnoException.h  TCLCommandPackage.h      TCLInterpreter.h
TCLString.h
Exception.h       TCLException.h           TCLInterpreterObject.h
TCLTimer.h
NamedItem.h       TCLFileHandler.h        TCLList.h
TCLVariable.h
RangeError.h     TCLHashTable.h          TCLObject.h
buffer.h
Refptr.h         TCLHashTableItem.h      TCLPackagedCommand.h
buftypes.h
StreamIOError.h  TCLHashTableIterator.h   TCLProcessor.h
daqtypes.h
TCLApplication.h TCLIdleProcess.h        TCLResult.h
histotypes.h

./src/include:
CAENHVWrapper.h  CAENHVWrapper.h.2.11  caenhvoslib.h  caenhvoslib.h.2.11
```

Directory source contains source files for everything you need to run HiRA HV GUI. There are source files for **caenctl** interface (extension to Tcl/tk). To remake the executable of caenctl one needs to run "make" command in the src/ directory. If these files are to be moved one needs to modify paths in the Makefile. Two paths are to be

changed: SRCDIR (directory where the source is) and INST_HV(directory where the HV GUI interface resides).