

Check list for shutdown Experiments

Stop run

Turn off

motherboard

Ramp down CAEN HV

Ramp down Tenelec

Turn off thermocouple

Turn off PLC power

Warm up cooler temperature to ~15 deg