

Check list for shutdown Experiments

Stop run Turn off motherboard Ramp down CAEN HV Ramp down Tenelec Ramp down
MCP target and MCP Turn off thermocouple Turn off PLC power Warm up cooler
temperature to ~15 deg