

u3pc2 (during the experiment) hosts the elog

To start elog if it is not in the server:

To start the server :

```
ssh u3pc2
```

```
goelog
```

a small "window ELOG SERVER" appears.

Now you can use elog in any DataU PC except u3pc2

```
goelogclient
```

To start the HV control

```
telenet caenhv05 1527
```

This will start up a HV window